


V3000 KNX **Air Conditioning Control System**

Technical NA08-137A

Operating instructions Radiofrequency remote control

09-2008



Remote control sleep mode:

To save its batteries, your remote control will automatically enter sleep mode if not used for approx. 35 seconds.

Temperature displayed:

Winter: 19°C Summer: 26°C

Corresponds to the middle point of the scale on the display:




Setting the comfort temperature control:



Press the button to raise the temperature or the button to lower the temperature in the room.

The scale will look like this



if the temperature is raised or

if the temperature is lowered.

On/Off button:

If (1) appears, the unit is off. The pictogram disappears when the unit operates in Comfort mode.

Fan speed selection button (each press of changes the setting):

AUTO = fan speed selected by your unit

= unit will run at low speed only = unit will run at medium speed only unit will run at high speed only.

Heating or Cooling:

If the appears, your unit is in cooling mode

If appears, your unit is in heating mode

If or appear, contact your CIAT service technician