


1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30																				
CONEXIONES FABRICA RACCORDMENTS USINE FACTORY CONNECTION							CONEXIONES CLIENTE RACCORDMENTS CLIENT CONNECTED BY CUSTOMER							CONEXIONES FABRICA RACCORDMENTS USINE FACTORY CONNECTION							CONEXIONES CLIENTE RACCORDMENTS CLIENT CONNECTED BY CUSTOMER																												
LINEA/LIGNE/PHASE 230 V....							1	OPTION D							CONEXION VALVULA INTERCAMBIADOR PISCINA ...RACCORDEMENT VANNE ECHANGEUR PISCINE CONNECTION SWIMMING POOL EXCHANGER VALVE							32																											
NEUTRO/NEUTRE/NEUTRAL 230 V							2								33																																		
LINEA/LIGNE/PHASE 24 V....							3								34																																		
NEUTRO/NEUTRE/NEUTRAL 24 V.							4								35																																		
COMUN PROTECCIONES COMMUN DES PROTECTIONS... PROTECTION COMMOM							5	MANDO ON/OFF REMOTO ...COMMANDE ON/OFF A DISTANCE CONTROL ON/OFF REMOTE							CONEXION SONDA IMPULSION PISCINA ...RACCORDEMENT SONDE SOUFFLAGE PISCINE CONNECTION SWIMMING POOL DISCHARGE SENSOR							36	SONDA AGUA RETORNO INTERCAMBIADOR/ ...SONDE EAU DE REPRIS ACHANGEUR EXCHANGER EXTERNAL WATER SENSOR ...COMUN SONDAS																										
							6								37																																		
							7								38																																		
							8								39																																		
							10	CONTACTO FALLO GENERAL ...CONTACT DEFALT GENERAL FAULT GENERAL CONTACT														40	SONDA AGUA IMPULSION INTERCAMBIADOR ...SONDE EAU REPRIS ECHANGEUR EXCHANGER DISCHARGE WATER SENSOR																										
							11															41										...SONDA AIRE RETORNO/SONDE AIR DE REPRIS/RETURN AIR SENSOR																	
							12															42																			...COMUN SONDAS								
							13															43																											
							14	CONEXION INTERRUPTOR DE CAUDAL / CONNECTION FLOW SWITCH														44	OPTION M																										
							15															45										CONEXION SONDA CO2 Y/O VOC ...RACCORDEMENT SONDE CO2 Y/O VOC CONNECTION SENSOR CO2 Y/O VOC																	
							16															46																											
							17															47																											
							18	CONEXION SONDA T+H AMBIENTE ...RACCORDEMENT SONDE T+H D'AMBIANCE CONNECTION AMBIENT T+H SENSOR														48																											
							19															49																											
							20															50																											
							21															51																											
							22	CONEXION SONDA T+H EXTERIOR ...RACCORDEMENT SONDE T+H EXTERIEURE CONNECTION EXTERNAL T+H SENSOR														52	OPTION F2																										
							23															53																											
							24															54																											
							25															55																											
OPTION A							26	CONEXION SONDA T+H AMBIENTE ...RACCORDEMENT SONDE T+H D'AMBIANCE CONNECTION AMBIENT T+H SENSOR														56	OPTION Z																										
							27															57																											
							28															58																											
							29															59																											
OPTION C							30	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														60																											
							31															61																											
							32															62																											
							33															63																											
							34	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														64																											
							35															65																											
							36															66																											
							37															67																											
							38	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														68																											
							39															69																											
							40															70																											
							41															71																											
							42	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														72																											
							43															73																											
							44															74																											
							45															75																											
							46	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														76																											
							47															77																											
							48															78																											
							49															79																											
							50	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														80																											
							51															81																											
							52															82																											
							53															83																											
							54	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														84																											
							55															85																											
							56															86																											
							57															87																											
							58	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														88																											
							59															89																											
							60															90																											
							61															91																											
							62	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														92																											
							63															93																											
							64															94																											
							65															95																											
							66	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														96																											
							67															97																											
							68															98																											
							69															99																											
							70	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														100																											
							71															101																											
							72															102																											
							73															103																											
							74	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														104																											
							75															105																											
							76															106																											
							77															107																											
							78	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														108																											
							79															109																											
							80															110																											
							81															111																											
							82	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														112																											
							83															113																											
							84															114																											
							85															115																											
							86	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														116																											
							87															117																											
							88															118																											
							89															119																											
							90	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														120																											
							91															121																											
							92															122																											
							93															123																											
							94	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														124																											
							95															125																											
							96															126																											
							97															127																											
							98	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														128																											
							99															129																											
							100															130																											
							101															131																											
							102	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														132																											
							103															133																											
							104															134																											
							105															135																											
							106	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														136																											
							107															137																											
							108															138																											
							109															139																											
							110	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														140																											
							111															141																											
							112															142																											
							113															143																											
							114	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														144																											
							115															145																											
							116															146																											
							117															147																											
							118	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														148																											
							119															149																											
							120															150																											
							121															151																											
							122	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														152																											
							123															153																											
							124															154																											
							125															155																											
							126	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														156																											
							127															157																											
							128															158																											
							129															159																											
							130	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														160																											
							131															161																											
							132															162																											
							133															163																											
							134	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														164																											
							135															165																											
							136															166																											
							137															167																											
							138	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														168																											
							139															169																											
							140															170																											
							141															171																											
							142	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														172																											
							143															173																											
							144															174																											
							145															175																											
							146	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														176																											
							147															177																											
							148															178																											
							149															179																											
							150	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														180																											
							151															181																											
							152															182																											
							153															183																											
							154	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														184																											
							155															185																											
							156															186																											
							157															187																											
							158	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														188																											
							159															189																											
							160															190																											
							161															191																											
							162	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														192																											
							163															193																											
							164															194																											
							165															195																											
							166	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														196																											
							167															197																											
							168															198																											
							169															199																											
							170	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														200																											
							171															201																											
							172															202																											
							173															203																											
							174	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														204																											
							175															205																											
							176															206																											
							177															207																											
							178	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														208																											
							179															209																											
							180															210																											
							181															211																											
							182	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														212																											
							183															213																											
							184															214																											
							185															215																											
							186	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														216																											
							187															217																											
							188															218																											
							189															219																											
							190	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														220																											
							191															221																											
							192															222																											
							193															223																											
							194	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														224																											
							195															225																											
							196															226																											
							197															227																											
							198	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														228																											
							199															229																											
							200															230																											
							201															231																											
							202	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														232																											
							203															233																											
							204															234																											
							205															235																											
							206	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														236																											
							207															237																											
							208															238																											
							209															239																											
							210	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														240																											
							211															241																											
							212															242																											
							213															243																											
							214	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														244																											
							215															245																											
							216															246																											
							217															247																											
							218	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														248																											
							219															249																											
							220															250																											
							221															251																											
							222	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														252																											
							223															253																											
							224															254																											
							225															255																											
							226	CONEXION SERVOMOTOR ...RACCORDEMENT SERVOMOTEUR CONNECTION SERVOENGINE														256																											
							227															257																											
							228															258																											
							229															259																											
							230	CONEXION VALVULA BAT. AGUA CALIENTE ...RACCORDEMENT VANNE BAT. EAU CHAUDE CONNECTION HOT WATER COIL VALVE														260																											
							231															261																											
							232															262																											


1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----


OPCIONALES / OPTIONS


- | | |
|---|---|
| <p>A - FREECOOLING Pg 4,8
FREECOOLING
FREECOOLING</p> <p>B - VENTILADOR RETORNO CENTRIFUGO - Pg 3,4,8
VENTILATEUR DE REPRISE CENTRIFUGE
RETURN CENTRIFUGAL FAN</p> <p>C - BATERIA AGUA CALIENTE - Pg 4,5,6,8
BATTERIE EAU CHAUDE
HOT WATER COIL</p> <p>D - INTERCAMBIADOR PISCINA - Pg 4,5,8
ECHANGEUR PISCINE
SWIMMING POOL EXCHANGER</p> <p>E - MANDO COMPATIDO REMOTO Pg 12
COMMANDE PARTAGÉ LOCAL
REMOTE SHARE CONTROL</p> <p>F1- MANDO PRIVADO LOCAL - pg 5,12
COMMANDE PRIVÉ LOCAL
LOCAL PRIVATE CONTROL</p> <p>F2- TERMINAL DE USUARIO TCO - pg 5,12,13
TERMINAL D'UTILISATEUR TCO
TCO USER TERMINALL</p> <p>K - DETECTOR FILTRO SUCIO - Pg 6
ENCRASSEMENT FILTRES
FILTER CLOGGING</p> | <p>L- RESISTENCIAS ELECTRICAS - Pg 3,7
BATTERIES ELECTRIQUES
ELECTRIC COIL</p> <p>I - TARJETA SERIAL RS485 - Pg
CARTE SERIAL RS485
RS485 SERIAL</p> <p>M - SENSOR CALIDAD AIRE AMBIENTE - pg 10
SONDE QUALITÉ AIR AMBIANCE
AIR QUALITY SENSOR FOR AMBIENT</p> <p>Q - CONTROL CAUDAL DE AIRE - Pg 6
CONTROLE DEBIT D'AIR
AIR FLOW CONTROL</p> <p>S - DETECTOR DE HUMOS - Pg 6,11
DETECTION DE FUMÉES
SMOKE DETECTION</p> <p>Z- DETECTOR DE FUGAS DE REFRIGERANTE - Pg 13
DETECCIÓN FUITE DE REFRIGERANT
REFRIGERANT LEAK DETECTOR</p> <p>AA- ALIMENTACION CON NEUTRO - Pg 3,4
ALIMENTATION AVEC NEUTRE
POWER SUPPLY WITH NEUTRAL</p> <p>AB- ALIMENTACION SIN NEUTRO - Pg 3,4
ALIMENTATION SANS NEUTRE
POWER SUPPLY WITHOUT NEUTRAL</p> <p>AC- ANTIHIELO BAC BAJA TEMPERATURA - Pg 6,8
ANTIGEL BAC BASSE TEMPERATURE
BAC ANTIFREEZE LOW TEMPERATURE</p> |
|---|---|

MODIFICADO POR: MODIFIÉ PAR: MODIFIED BY:		C.R.G.	FECHA: DATE: DATE:		05/03/2015	SERIE : BCP		MODELO: MODELE:		0480 -	GRUPO DE DESHUMECTACION POR BOMBA DE CALOR OPCIONALES: BATERIA AGUA CALIENTE. INTERCAMBIADOR PISCINA. REG. CIAT-POOL.			3 COMPRESORES/3 CIRCUITOS 3 COMPRESSEURS/3 CIRCUITS 3 COMPRESSORS/3 CIRCUITS			
MODIFICACION: MODIFICATION:		SONDA T+H EXTERIOR - OPC A -				Vº Bº				NP :	77480D3-02			PAGINA PAGE		TENSION VOLTAGE	
SUSTITUYE A: REPLACE: TAKE:		77480D1-01		SUSTITUIDO POR: REPLACÉ PAR: TAKE BY:		-				NF :				2 / 15		400 / 3 / 50	











1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----




CAJA DE CONEXION PRESOSTATOS DE ALTA Y BAJA
CAJA 100 X 100 PVC

MODIFICADO POR: MODIFIE PAR: MODIFIED BY:		C.R.G.	FECHA: DATE: DATE:		05/03/2015	SERIE : BCP		MODELO: 0480 MODELE: -		GRUPO DE DESHUMECTACION POR BOMBA DE CALOR OPCIONALES: BATERIA AGUA CALIENTE. INTERCAMBIADOR PISCINA. REG. CIAT-POOL.			3 COMPRESORES/3 CIRCUITOS 3 COMPRESSEURS/3 CIRCUITS 3 COMPRESSORS/3 CIRCUITS					
MODIFICACION: MODIFICATION:		SONDA T+H EXTERIOR - OPC A -				Vº Bº		NP : 77480D3-02					PAGINA PAGE		TENSION VOLTAGE			
SUSTITUYE A: REPLACE: TAKE:		77480D1-01		SUSTITUIDO POR: REPLACÉ PAR: TAKE BY:		-				NF :					7/15		400/3/50	




1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----



MODIFICADO POR: MODIFIE PAR: MODIFIED BY:		C.R.G.	FECHA: DATE: DATE:		05/03/2015	SERIE : BCP		MODELO: MODELE:		0480 -	GRUPO DE DESHUMECTACION POR BOMBA DE CALOR OPCIONALES: BATERIA AGUA CALIENTE. INTERCAMBIADOR PISCINA. REG. CIAT-POOL.			3 COMPRESORES/3 CIRCUITOS 3 COMPRESSEURS/3 CIRCUITS 3 COMPRESSORS/3 CIRCUITS	
MODIFICACION: MODIFICATION:		SONDA T+H EXTERIOR - OPC A -				Vº Bº			NP:	77480D3-02				PAGINA PAGE	TENSION VOLTAGE
SUSTITUYE A: REPLACE: TAKE:		77480D1-01	SUSTITUIDO POR: REPLACE PAR: TAKE BY:		-				NF:	-				8/15	400/3/50





1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

OPTION S

DH: CENTRAL DETECCION HUMOS
DH: CENTRAL DETECTEUR DE FUMMEE
DH: SMOKE DETECTION CENTRAL

CARAIBES DADC 1601

LED ENCENDIDO ESTADO CORRECTO
LED ALLUME ETAT CORRECT
RIGHT STATUS LED ON

REARME/REARMEMENT/RESET

DH

ALIMENTACION
ALIMENTATION
SUPPLY
230 V.

REPORT

BBG COMMANDE R DETECTION
DIST - + A R C


T N Ph
1 2 3

M - +
1 2 3 4 5 6 7 8 9 10 11

A R C
1 2 3 4 5 6 7 8 9 10 11



A C
6-8




SONDA DETECTOR DE
HUMOS MODELO CAPI00
SONDE DETECTEUR DE
FUMES MODELE CAPI00
SMOKE DETECTOR SENSOR
MODELE CAPI00

MODIFICADO POR: MODIFIE PAR: MODIFIED BY:	C.R.G.	FECHA: DATE: DATE:	05/03/2015	SERIE :	BCP	MODELO: MODELE:	0480 -	GRUPO DE DESHUMECTACION POR BOMBA DE CALOR OPCIONALES: BATERIA AGUA CALIENTE, INTERCAMBIADOR PISCINA, REG. CIAT-POOL.	3 COMPRESORES/3 CIRCUITOS 3 COMPRESSEURS/3 CIRCUITS 3 COMPRESSORS/3 CIRCUITS
MODIFICACION: MODIFICATION:	SONDA T+H EXTERIOR - OPC A	V° B°				NP:	77480D3-02		PAGINA PAGE
SUSTITUYE A: REPLACE: TAKE:	77480D1-01	SUSTITUIDO POR: REPLACÉ PAR: TAKE BY:	-			NF:	-		TENSION VOLTAGE
									11/15
									400/3/50



OPTION Z

DPWLE27000
IP66 R410A



CONFIGURACION VELOCIDAD DE COMUNICACION
CONFIGURATION COMMUNICATION SPEED
(9600 bd)

PASOS /STEP :

$$\begin{aligned} SW1 &= E \\ SW2 &= F \end{aligned}$$

2º
GUITAR TENSION Y DAR TENSION / OFF POWER AND ON POWER

3º
VELOCIDAD COMUNICACION/ COMMUNICATION SPEED: 9600 bd

CONFIGURACION JUMPER / JUMPER CONFIGURATION

JI = PRESENTE / PRESENT - AC

J2 = NO PRESENTE / NOT PRESENT - DC

J3 = PRESENTE / PRESENT - SEÑAL AUDIBLE HABILITADA / ENABLE AUDIBLE SIGNAL


J4 = JUMPER RESET

J5 -J6 = NO PRESENTE / NOT PRESENT - NO DELAY (RS-485 COMUNICATION)

```
SW1 = 6 } DIRECCION COMUNICACION - COMMUNICATION ADDRESS
SW2 = 0 }
```

MODIFICADO POR: MODIFIÉ PAR: MODIFIED BY:		C.R.G.	FECHA: DATE: DATE:		05/03/2015	SERIE : BCP		MODELO: 0480 MODELE: -		GRUPO DE DESHUMECTACION POR BOMBA DE CALOR OPCIONALES: BATERIA AGUA CALIENTE. INTERCAMBIADOR PISCINA. REG. CIAT-POOL.				3 COMPRESORES/3 CIRCUITOS 3 COMPRESSEURS/3 CIRCUITS 3 COMPRESSORS/3 CIRCUITS			
MODIFICACION: MODIFICATION:		SONDA T+H EXTERIOR - OPC A -				V° B°				NP : 77480D3-02				PAGINA PAGE		TENSION VOLTAGE	
SUSTITUYE A: REPLACE: TAKE:		77480D1-01		SUSTITUIDO POR: REPLACÉ PAR: TAKE BY:		-				NF :				13/15		400/3/50	


1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----



MODIFICADO POR: MODIFIÉ PAR: MODIFIED BY:	C.R.G.	FECHA: DATE: DATE:	05/03/2015	SERIE : BCP	MODELO: 0480 MODELE: -	GRUPO DE DESHUMECTACION POR BOMBA DE CALOR OPCIONALES: BATERIA AGUA CALIENTE, INTERCAMBIADOR PISCINA, REG. CIAT-POOL.	3 COMPRESORES/3 CIRCUITOS 3 COMPRESSEURS/3 CIRCUITS 3 COMPRESSORS/3 CIRCUITS
MODIFICACION: MODIFICATION:	SONDA T+H EXTERIOR - OPC A	Vº Bº			NP: 77480D3-02		PAGINA PAGE
SUSTITUYE A: REPLACE: TAKE:	77480D1-01	SUSTITUIDO POR: REPLACÉ PAR: TAKE BY:	-		NF:		14/15
							TENSION VOLTAGE
							400/3/50

	CANAleta	ALTO	ANCHO	LONGITUD
C1	1918720	60	20	500
C2	1918720	60	20	480
C3	1918720	60	20	770
C4	1918720	60	20	790
C5	1918720	60	20	550
C6	1918720	60	20	150
TOTAL				

IMPLANTACION
 DE PLETINA
 IMPLANTATION DE
 PLATINE
 ELECTRICAL
 PANEL LOCATION



IMPLANTACION
DE PLETINA
IMPLANTATION DE
PLATINE
ELECTRICAL
PANEL LOCATION